

STNR | Surface Mount / Retrofit Installation

Ideal for any application that allows the nosing to be mounted with adhesive. Install on existing stairs in High Rise Buildings, Stadiums, Bleachers, Industrial Plants, Homes, Businesses, Schools – Interior or Exterior. Applies to concrete, aluminum, wood, or any other clean, dry, flat surface.

For compliant placement of egress path markings, consult your applicable local or national codes (2009, 2012 IBC section 1024 + 2015 IBC section 1025).

Installation Steps:

1. Verify the surface is clean, dry, flat and smooth.
 - On concrete, use a leveling compound if necessary, to provide a level/smooth surface.
 - Use dry cloth and non-residue cleaning compound to remove dirt and grime.

2. Use construction grade (water resistant) adhesive.
 - Recommended Adhesive: Bostik 1100FS or 70-03A.
 - Place nosing in place, centered on front edge of tread.
 - Apply continuous bead of adhesive (centered) on underside of nosing.

3. Place and press nosing centered on front edge of tread.
 - Tape the nosing in place with painter's tape while curing.
 - Allow adhesive rated cure time before stair use.

Installation Inspection:

Check regularly for loose nosing's or damaged components. Replace damaged components, repair delaminated Photo-Glo components as required.

Photo-Glo Charge Instruction:

Minimum of 1-foot candle (11 Lux) of fluorescent, incandescent or LED (light emitting diode) for 60 Minutes is required to charge Photo-Glo.

Control of lighting restricted to authorized personnel. Reliable external illumination is always required during building occupancy.

Do not use Photo-Glo where the ambient illumination level is less than 1-foot candle (11 Lux).

If you have further questions, please contact us:

Call: 1-855-723-6673 Email: sales@safetnose.com